

HIGHLEAD

GC20698-5/-6/-7/-8

**Compound-Feed, Heavy Duty
Lockstitch Sewing Machine**

**Instruction Manual
Parts Catalog**

—INDEX—

OPERATION INSTRUCTION

| | |
|--|----|
| 1. PRECAUTIONS BEFORE STARTING OPERATION | 1 |
| 2. SPECIFICATIONS | 1 |
| 3. SETTING UP THE MACHINE..... | 2 |
| 4. OILING..... | 2 |
| 5. NEEDLE..... | 3 |
| 6. THREAD..... | 4 |
| 7. WINDING THE LOWER THREAD ON THE BOBBIN..... | 4 |
| 8. REMOVE AND INSERT THE BOBBIN..... | 4 |
| 9. THREADING THE NEEDLE..... | 5 |
| 10. REGULATING THE THREAD TENSION..... | 5 |
| 11. ADJUSTMENT OF THE STITCH LENGTH..... | 6 |
| 12. ADJUSTMENT OF THE PREESURE | 6 |
| 13. REVERSE STITCH..... | 6 |
| 14. WIDTH OF ZIGZAG AND LENGTH OF STITCH..... | 7 |
| 15. ADJUSTMENT THE HEIGHT OF THE FEED DOG..... | 7 |
| 16. TIMING BETWEEN THE HOOK AND THE NEEDLE..... | 8 |
| 17. ADJUSTMENT OF BOBBIN CASE OPENER..... | 9 |
| 18. THE HEIGHT OF THE PRESSER FEET | 9 |
| 19. TIMING OF THE VIBRATING AND LIFTING PRESSER FEET..... | 10 |
| 20. THE CLEARANCE OF THE VIBRATING AND LIFTING PRESSER FEET..... | 10 |
| 21. ADJUSTMENT OF THE THREAD CONTROLLER SPRING..... | 11 |
| 22. REPLACEMENT OF THE CONNECTION BELT..... | 11 |
| 23. TO RE-ENGAGE THE SAFETY CLUTCH..... | 12 |
| 24. ADJUSTMENT OF THE OILING FOR THE HOOK SADDLE..... | 13 |

PARTS CATALOG

| | |
|--------------------------------------|----|
| A. ARM BED AND IT'S ACCESSORIES..... | 14 |
| B. ARM SHAFT MECHANISM..... | 17 |
| C. PRESSER FOOT MACHANISM..... | 20 |

| | |
|--|----|
| D. STITCH REGULATOR MACHANISM..... | 23 |
| E. HOOK SHAFT MECHANISM..... | 26 |
| F. THREAD TENSION REGULATOR MACHANISM..... | 29 |
| G. PARTS FOR SINGEL NEEDLE..... | 32 |
| H. PARTS FOR TWIN NEEDLE..... | 34 |
| I. SPECIAL PARTS FOR 20"..... | 35 |
| J. ACCESSORIES..... | 37 |

1. PRECAUTIONS BEFORE STARTING OPERATION

1) Safety precautions

(1) When turning the power on, keep your hands and fingers away from the area around/under the needle and the area around the pulley.

(2) Power must be turned off when the machine is not in use, or when the operator leaves the seat.

(3) Power must be turned off when tilting the machine head, installing or removing the "V" belt, adjusting the machine, or when replacing.

(4) Avoid placing fingers, hairs, bars etc., near the pulley, "V" belt, bobbin winder pulley, or motor when the machine is in operation.

(5) Do not insert fingers into the thread take-up cover, under/around the needle, or pulley when the machine is in operation.

(6) If a belt cover, finger guard, eye guard are installed, do not operate the machine without these safety devices.

2) Precautions before starting operation

(1) If the machine's oil pan has an oil sump, never operate the machine before filling it.

(2) If the machine is lubricated by a drop oiler, never operate the machine before lubricating.

(3) When a new sewing machine is first turned on, verify the rotational direction of the pulley with the power on. (The pulley should rotate counterclockwise when viewed from the pulley).

(4) Verify the voltage and (single or three) phase with those given on the machine nameplate.

3) Precautions for operating conditions

(1) Avoid using the machine at abnormally high temperatures (35°C or higher) or low temperatures (5°C or lower) .

(2) Avoid using the machine in dusty conditions.

2. SPECIFICATIONS

| | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 |
|------------------------|---|---|-------------|---|
| MAX. SPEED (s. p. m.) | 1,200 | | | |
| MAX. STITCH (mm) | 10 | | | |
| MAX. LIFT OF FOOT (mm) | 20 | | | |
| NEEDLE | DY × 3 (standard No. 24) • SY5213 • 794 | | | |
| BOBBIN SIZE (mm) | Φ37 × 13 | | | |
| WORKING SPACE (mm) | 508 × 153 | | 762 × 153 | |
| BED DIMENSION (mm) | 846 × 230 | | 1,100 × 230 | |
| NEEDLE SPACING | — | 3/4" (19mm) (standard) 1/4" (6.4 mm) ~ 1-3/4" (44.5mm) | — | 3/4" (19mm) (standard) 1/4" (6.4 mm) ~ 1-3/4" (44.5mm) |

USE FOR: Tent, Sailcloth, Rubberized, Fabrics, Heavy Synthetic, Heavy Upholstery Materials, Fiber Plate, Leather, Etc.

3. SETTING UP THE MACHINE (Fig. 1)

Setting up the machine on the table after removed two pieces of supporting bolts (A) under the bed.




Fig.1

4. OILING (Figs. 2, 3, 4 & 5)

Oil should be applied at each of the place designated by arrows in Figs. 2, 3, 4&5.




Fig.2




Fig.3




Fig.4




Fig.5

To fill the oil for reservoir of hook saddle from the hole after taken out the oil gauge A (Fig. 6) and pour the oil until the oil level reached to the upper reference line B of the oil gauge (Fig. 6-1) .

When in continuous use, it should be oiled at least twice a day.




Fig.6




Fig.6-1

5. NEEDLE (Figs. 7 & 8)

HIGHLEAD GC20698-5,-6,-7,-8 series machines are set up to use standard needle of DY×3 (standard No. 24) ·SY5213·794. The size of needle to be used should be determined by the size of thread, type and thickness of the sewing materials.

To insert the needle, turn the machine pulley over toward you until the needle bar moves up to its highest point, put the needle up into the needle bar as deeply as it will go, with the long groove of the needle faced outside.

Tighten the needle set screw securely.




Fig.7




Fig.8

6. THREAD (Fig. 9)

Normally, left twisted thread is used for upper (needle) thread. (But, for left side needle of twin-needle machine, it can be finished in fine results with right twisted thread) .




Fig.9

7. WINDING THE LOWER THREAD ON THE BOBBIN (Figs. 10 & 11)

Pass the thread through (1) - (4) , and wind several times around the bobbin, which set up to the shaft of bobbin winder.

Press the lever (5) to arrow direction, then the bobbin winds the thread automatically, in engage with the operation of the machine.

The bobbin will automatically be stopped after the bobbin is filled with thread.




Fig.10




Fig.11

8. REMOVING AND INSERTING THE BOBBIN (Figs. 12 & 13)

Draw back the side plate (1) on the bed of the machine, and raise the hinged latch (2) to a vertical position, then remove and insert the bobbin.

Insert the bobbin and pull thread (3) out about 4-5cm, then push down the hinged latch (2) and draw the thread end under the tension spring (4) .

When closing the side plate (1) , leave just enough space for the thread to pass through.




Fig.12




Fig.13

9. THREADING THE NEEDLE (Figs. 14 & 15)

Pass the thread from thread guide (1) -eyelet (2) -tension disc (3) -tension thread guide (4) -guide (5) -thread take-up spring (6) -guide (7) -take-up lever (8) -guide (7) -lower guide (9) -self threading needle bar thread guide (10) -through the eye of the needle (11). (Remark) Wind the thread a single time to tension thread guide (4) .

With the left hand hold the end of the needle thread leaving it slack from the hand to the needle. Turn the machine pulley over toward you until the needle moves down and up again to its highest point, thus catching the bobbin thread, draw up the needle thread, and the bobbin thread will come up with it through the hole in the feed dog.

Lay the thread back under the presser feet and close the slide.




Fig.14




Fig.15

10. REGULATING THE THREAD TENSION (Figs. 16 & 17)

The tension on the needle thread is regulated by the thumb nut A (Fig. 16) .

The tension on the bobbin thread is regulated by the screw of the tension spring on the outside of the bobbin case B (Fig. 17) .

To increase the tension, turn over nut A or screw to the right, and to decrease the tension, turn over nut or screw to the left.




Fig.16




Fig.17

11. ADJUSTMENT OF THE STITCH LENGTH (Fig. 18)

The length of stitch is regulated by pressing down the button (1) with left hand, while turning the machine pulley (2) slowly with right hand in the condition of setting the top of button (1) to the feed eccentric.

To increase the length of stitch, turn the machine pulley over toward you.

To decrease the length of stitch, turn the machine pulley to opposite direction.

When the desired length of stitch is obtained, operate the machine after fully confirmed releasing the button (1) to the original position.




Fig.18




Fig.19

12. ADJUSTMENT OF THE PRESSURE (Fig. 19)

The pressure of the presser feet is regulated by the adjusting screw.

To increase the pressure, turn the screw to clockwise, and decrease it, turn the screw to counter-clockwise.

13. REVERSE STITCHING (Fig. 20)

The chain for the feed reversing pedal is connected to the hook of feed reversing lever A underneath of the bed of the machine.

To feed the work toward you, press down firmly on the feed reversing pedal, and do not stop to press down on the way.




Fig.20

14. RELATIVE POSITION OF VIBRATING AND LIFTING PRESSER BAR, OF THE NEEDLE AND THE NEEDLE HOLE OF THE FEEDER (Figs. 21 & 22)

The distance between the vibrating presser bar (1) and lifting presser bar(2), after adjusting the feed eccentric so that there is no feed movement of the needle bar, should be 15.5 mm (one needle) and 14.5 mm (two needle) .To adjust by the screws for connecting crank (3).

Normally, relative position of the feed dog against the needle, the needle should be passed through the center of the needle hole of the feed dog .

To adjust by the screw for the feed rock shaft bell crank(4).

Securely tighten the screws after finished adjustment.




Fig.21




Fig.22

15. ADJUSTMENT THE HEIGHT OF THE FEED DOG (Figs. 23,24 & 25)

The maximum height of the feed dog from the surface of the needle plate is normally 1.3 mm.

To adjust this height by the screw on the feed lifting cam fork of the feed bar and raise or lower the feed dog, as may be required, and retighten the screw (1) .




Fig.23




Fig.24

Fig.25

16. TIMING BETWEEN THE HOOK AND THE NEEDLE (Fig. 26)

Set the feed eccentric with the button at no feeding position, and confirm the length between vibrating and lifting presser bar should be 15.5 mm.

If the needle bar and sewing hook are correctly timed, the point of the hook will be at the center of the needle when the needle raised 3.8 mm + 0.5 mm from the lowest point.

1) Adjustment of the timing

(1) For the adjustment of timing, loosen 2 screws (1) for hook driving gear, and tap this gear to the right or left in clearance of 2 mm on the hook driving shaft until the point of the hook is at the center of the needle.

(2) Tapping to the right gives on earlier hook timing, and to the left gives later hook timing.

(3) Except the above case, to adjust in changing gear condition between hook driving gear (2) and hook shaft gear (3) .

(4) Securely tighten the two set screws for hook driving gear after finished adjustment

2) Adjustment of the clearance

Normal clearance between hook point and scarf of the needle is in 0.02 - 0.1 mm

(1) Loosen two screws (4) and (5) for hook saddle.

(2) Move hook saddle to right or left, as may be required, until hook point is as close to needle as possible without striking it.

(3) Then securely tighten two screws.

(4) To check the needle with careful attention free from bent before adjustment.

3) Height of the needle bar (Fig. 27)

Normal clearance between top of the eye of the needle and hook point is 2.2 mm .

In case the needle bar is incorrectly set, loose the needle bar connecting stud pinch screw (A) and place the needle bar in correct position as required above, then retighten the screw (A) .




Fig.26





Fig.27



17. ADJUSTMENT OF BOBBIN CASE OPENER (Fig. 28)

(1) Turn the machine pulley or hand wheel (GC20698-6,-8 series machine) until the top of the opener is located at the distance from the needle plate.

(2) In this position, adjust it so that the clearance A between the inside edge of the opener and the top of the hook is about 0.3 - 0.8 mm.

(3) Securely tighten the screw B after finished adjustment.




Fig.28




Fig.29

18. THE HEIGHT OF THE PRESSER FEET (Figs. 29,30 & 31)

Normal distance between the surface of the needle plate (A) and vibrating presser foot at stopped position of the stop lever (C) is 19 mm.

When step on the lifting pedal, the stop lever (C) will be released by the lifting lever (B).

To change the relative lift of the presser feet, loosen the screw (1) at the above condition.

The height of lift of the presser feet is adjustable by moving the screw of presser bar lifting bracket.

Normal distance between presser bar position guide bracket (3) and presser bar position guide (4) is 7 mm.

Position of the vibrating presser foot to shift in left and right is to be adjusted by the screw (2) for presser bar lifting bracket and the screw (5) for presser bar position guide bracket.




Fig.30




Fig.31


19. TIMING OF THE VIBRATING AND LIFTING PRESSER FEET (Fig. 32)

The amount of lift of the vibrating and lifting presser feet should be regulated according to the thickness of materials being sewn.

The feet should lift just enough to clear the materials.

As a rule, the vibrating and lifting presser feet should lift an equal height, but some grades of work may require that they lift an unequal height.

To change the relative lift of the presser feet, loosen the screw (A) for lifting rock shaft crank and move the vibrating presser bar upward or downward as required, then securely tighten the screw (A) .



Upper Surface




Fig.32

20. THE CLEARANCE OF THE VIBRATING AND LIFTING PRESSER FEET

(Fig. 33)

The amount of the lift of the alternating feed for the vibrating and lifting presser feet are to be adjusted by the lifting bell crank link screw stud (1) .

To decrease the movement in setting the stud (1) at the upper position, and to increase the movement in setting the stud (1) at the lower position. After setting to the required position, securely tighten the stud (1) with nut (2) .

The clearance for the vibrating and lifting presser feet are being adjusted at maximum, so that the clearance of them should be adjusted according to the materials being sewn.

The timing position for the vibrating and lifting presser feet should be regulated by Fig. 32.




Fig.33

21. ADJUSTMENT OF THE THREAD CONTROLLER SPRING (Fig. 34)

For more controller action on the thread, loosen the set screw (1) at the right of the controller and set the stop lever, and for less action set the stop higher.

To strengthen the action of the controller spring on the thread, loosen the spring stud screw (4) at the rear of the stop screw and turn the spring stud (5) slightly to the left with a screwdriver, or lighten its action turn to the right and securely retighten the spring stud screw.




Fig.34

22. REPLACEMENT OF THE CONNECTION BELT

1) When the connection belt removed from the pulley for adjusting and or replacing purposes of the parts (Figs. 35 & 36)

(1) Turn the machine pulley toward you so that placed the take-up lever(A) at the highest position.

(2) Turn the hook shaft with the fingers until the arrow mark (2) on the hook driving shaft bushing collar and the red point mark (1) on the hook driving shaft bushing are directly in line.

(3) Then replace the belt over the upper and lower pulley.




Fig.35




Fig.36

2) Replacement of the connection belt when damaged (Figs. 37 & 38)

(1) Remove the upper arm plate and reservoir.

(2) Slide the connection belt (A) off from lower and upper belt pulley.

(3) Loosen the machine pulley adjustment screw (2) and two set-screws for the machine pulley (3), then remove the machine pulley.

(4) Loosen the three screws in the arm shaft bushing (5) and remove the bushing (6) .

(5) Lift the belt up through the arm cap hole after removed the bushing (6) as far as possible and draw it out through the space normally occupied by the bushing.

(6) Replace the connection belt as opposite processes as above for removing it.

(7) Securely tighten all the screws, so as to fit the arm shaft, firmly, free from looseness.




Fig.37




Fig.38

23. TO RE-ENGAGE THE SAFETY CLUTCH (Figs. 39 & 40)

The hook driving shaft and the shaft of the sewing hook are splined to prevent the hook from getting out of time. The safety clutch located in the lower belt pulley prevents damage in the event of thread jamming in the sewing hook by releasing the locking lever in the pulley.

Take out jammed thread from the hook.

To re-engage the clutch, press down the lock stud (A) , near the base of the arm by left hand and turn the machine pulley backward slowly by right hand, then the safety clutch will be released.

In the case easily releasing the safety clutch, adjust the pressure by the screw (B) for lower belt pulley after removed connection belt (C) .

To increase the pressure in turning the screw (B) to clockwise and to decrease the pressure in turning the screw (B) to counter-clockwise.




Fig.39




Fig.40

24. ADJUSTMENT OF THE OILING FOR THE HOOK SADDLE (Fig. 41)

Loosen the screw for the oil adjustment dial (3) and adjust oil supply by turning the oil adjustment dial (2). Maximum oil supply at the directly in line of the point mark (1) on the hook saddle and the center line of the dial (2). Stop the oil supply at the vertical position of the center line of the dial (2).





Fig.41

A. ARM BED AND ITS ACCESSORIES




A. ARM BED AND ITS ACCESSORIES

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|--|-----------|-----------|-----------|-----------|---------|
| A01 | HE924B7101 | Foot lifter lifting lever latch handle | 1 | 1 | 1 | 1 | |
| A02 | HA100B2110 | Set screw | 3 | 3 | 3 | 3 | |
| A03 | HE913B8001 | Collar (upper) | 1 | 1 | 1 | 1 | |
| A04 | H7214H8001 | screw | 1 | 1 | 1 | 1 | |
| A05 | HE915B8001 | Foot lifter lifting lever latch spring | 1 | 1 | 1 | 1 | |
| A06 | HE916B8001 | Collar (lower) | 1 | 1 | 1 | 1 | |
| A07 | HA100C2170 | Set screw | 1 | 1 | 1 | 1 | |
| A08 | HE917B8001 | Foot lifter lifting lever latch | 1 | 1 | 1 | 1 | |
| A09 | HE918B8001 | Foot lifter lifting lever | | | 1 | 1 | |
| A10 | HE919B8001 | Pin | 1 | 1 | 1 | 1 | |
| A11 | HE920B8001 | Foot lifter lifting lever hinge stud | 1 | 1 | 1 | 1 | |
| A13 | HE921B8001 | Foot lifter lifting lever spring | 1 | 1 | 1 | 1 | |
| A14 | HE048D8001 | Screw | 1 | 1 | 1 | 1 | |
| A15 | H7014D7101 | Down-lead complete | 1 | 1 | 1 | 1 | |
| A16 | HE021B8001 | Nut | 1 | 2 | 1 | 2 | |
| A22 | HE949B8001 | Lubricating oil cup (front). | | | 1 | 1 | |
| A23 | HE950B8001 | Oil pad | | | 1 | 1 | |
| A24 | HE930B8001 | Oil wick (A) | | | 1 | 1 | |
| A25 | HE931B8001 | Vinyl tube (A) | | | 1 | 1 | |
| A26 | HE951B8001 | Arm cap (front) | | | 1 | 1 | |
| A27 | HE045D8001 | Washer | 1 | 1 | 2 | 2 | |
| A28 | H2015I0065 | Stop screw | 1 | 1 | 2 | 2 | |
| A29 | HE928B8001 | Lubricating oil cup | 1 | 1 | 1 | 1 | |
| A30 | HE111F8001 | Set screw | | 1 | 1 | 1 | |
| A31 | HE929B8001 | Oil pad | | 1 | 1 | | |
| A32 | HE932B8001 | Oil wick | | 1 | | | |
| A33 | HE933B8001 | Vinyl tube | 1 | 1 | | 1 | |
| A34 | HE930B8001 | Oil wick | 1 | 1 | 1 | 1 | |
| A35 | HE931B8001 | Vinyl tube | 1 | 1 | 1 | 1 | |
| A36 | HE934B8001 | Arm cap | 1 | 1 | 1 | 1 | |
| A40 | H7327B8001 | Arm oil plug | 1 | 1 | 1 | 1 | |
| A41 | HE020B8001 | Thread guide | 1 | 2 | 1 | 2 | |
| A42 | HE937B8001 | Face plate | 1 | 1 | 1 | 1 | |
| A43 | HE938B8001 | Face plate thumb screw | 1 | 1 | 1 | 1 | |
| A44 | HE939B8001 | Thread guide (lower) | 1 | 1 | 1 | 1 | |
| A45 | HE025C8001 | Screw | 2 | 2 | 2 | 2 | |
| A46 | HE940B8001 | Throat plate. | | 1 | | 1 | |
| A47 | HE005H8001 | Throat plate screw | 1 | 1 | 1 | 1 | |
| A48 | HE006H8001 | Throat plate position screw | 1 | 1 | 1 | 1 | |
| A49 | H3200B2130 | Throat plate stop | 1 | 1 | 1 | 1 | |
| A50 | HE942B8001 | Bed slide (left) | | 1 | | 1 | |

A. ARM BED AND ITS ACCESSORIES

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|--------------|---------------|---------------------------------------|-----------|-----------|-----------|-----------|---------|
| A51 | HE943B8001 | Bed slide (right) | | 1 | | 1 | |
| A52 | HE946B8001 | Bed slide stop | 1 | 1 | 1 | 1 | |
| A53 | HE009H8001 | Bed slide stop spring | 1 | 1 | 1 | 1 | |
| A54 | HE944B8001 | Bed plate (front) | 1 | 1 | 1 | 1 | |
| A55 | HE013H8001 | Screw | 1 | 1 | 1 | 1 | |
| A56 | HE957B8001 | Arm cross shaft bushing | | | 1 | 1 | |
| A57 | HE014C8001 | Oil wick | | | 1 | 1 | |
| A58 | HE040D8001 | Set screw | 1 | 1 | 1 | 1 | |
| A59 | HE958B8001 | Arm cross shaft gear | | | 1 | 1 | |
| A60 | HE017G8001 | Position screw | | | 1 | 1 | |
| A61 | HE023C8001 | Position screw | | | 1 | 1 | |
| A62 | HE959B8001 | Hand wheel driving gear | | | 1 | 1 | |
| A63 | HE022G8001 | Set screw | | | 1 | 1 | |
| A64 | HE960B8001 | Set screw | | | 1 | 1 | |
| A65 | HE961B8001 | Hand wheel disengaging spring plunger | | | 3 | 3 | |
| A66 | HE962B8001 | Hand wheel disengaging spring | | | 3 | 3 | |
| A67 | HE963B8001 | Hand wheel | | | 1 | 1 | |
| A68 | HE964B8001 | Hand wheel engaging plate | | | 1 | 1 | |
| A69 | HA700F2100 | Screw | | | 4 | 4 | |
| A70 | HE965B8001 | Arm cross shaft | | | 1 | 1 | |
| A71 | HE956B8001 | Machine supporting bolt | 3 | 3 | 3 | 3 | |
| A72 | H8000H2070 | Foot lifter lifting lever chain hook | 1 | 1 | 1 | 1 | |
| A73 | H2000M0090 | Ball oiler | 5 | 5 | 5 | 5 | |
| A74 | HA700F2100 | Screw | | | 1 | 1 | |

B. ARM SHAFT MECHANISM




B. ARM SHAFT MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|----------------------------------|-----------|-----------|-----------|-----------|---------|
| B01 | HE904C8001 | Arm shaft | | | 1 | 1 | |
| B02 | HE905C8001 | Take-up lever | 1 | 1 | 1 | 1 | |
| B03 | HE906C8001 | Take-up lever hinge stud | 1 | 1 | 1 | 1 | |
| B04 | HE907C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| B05 | HE020C8001 | Set screw | 2 | 2 | 2 | 2 | |
| B06 | HA100B2150 | Cap | 2 | 2 | 2 | 2 | |
| B07 | HE908C8001 | Take-up lever driving stud | 1 | 1 | 1 | 1 | |
| B08 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| B09 | HE909C8001 | Needle bar connecting link | 1 | 1 | 1 | 1 | |
| B10 | HE910C8001 | Needle bar crank | 1 | 1 | 1 | 1 | |
| B11 | HA100C2070 | Position screw | 1 | 1 | 1 | 1 | |
| B12 | HE013C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B13 | HA100C2060 | Set screw | 1 | 1 | 1 | 1 | |
| B14 | H3100C2070 | Needle bar connecting link stud | 1 | 1 | 1 | 1 | |
| B15 | HE041C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| B16 | HE013C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B17 | HE911C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B18 | HE011C8001 | Needle bar crank friction washer | 1 | 1 | 1 | 1 | |
| B19 | HE912C8001 | Arm shaft bushing (front) | 1 | 1 | 1 | 1 | |
| B20 | HE014C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| B21 | HE010G8001 | Oil pad | 1 | 1 | 1 | 1 | |
| B22 | HE028C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B23 | HE914C8001 | Feed driving eccentric | 1 | 1 | 1 | 1 | |
| B24 | HE023C8001 | Set screw | 2 | 2 | 2 | 2 | |
| B25 | HE915C8001 | Arm shaft center bushing (front) | 1 | 1 | 1 | 1 | |
| B26 | HE014C8001 | Oil pad | 1 | 1 | 1 | 1 | |
| B27 | HE020C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B28 | HE916C8001 | Arm shaft center bushing | 1 | 1 | 1 | 1 | |
| B29 | HE014C8001 | Oil pad | 1 | 1 | 1 | 1 | |
| B30 | HE020C8001 | Set screw | 1 | 1 | 1 | 1 | |
| B31 | HE026C8001 | Arm shaft connection belt pulley | 1 | 1 | 1 | 1 | |
| B32 | H3205C0661 | Spring flange | 2 | 2 | 2 | 2 | |
| B33 | HE006D8001 | Set screw | 1 | 1 | 1 | 1 | |
| B34 | HE030C8001 | Check screw | 1 | 1 | 1 | 1 | |
| B35 | HE028C8001 | Position screw | 1 | 1 | 1 | 1 | |
| B36 | HE917C8001 | Connection belt | 1 | 1 | 1 | 1 | |
| B37 | HE918C8001 | Arm shaft bushing | | | 1 | 1 | |
| B38 | HE014C8001 | Oil pad | | | 1 | 1 | |
| B39 | HE919C8001 | Set screw | | | 3 | 3 | |
| B40 | HE920C8001 | Machine pulley | | | 1 | 1 | |
| B41 | HE038E8001 | Set screw | | | 2 | 2 | |

B. ARM SHAFT MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|------------------------------------|-----------|-----------|-----------|-----------|---------|
| B42 | HE007C8001 | Machine pulley adjusting screw | 1 | 1 | 1 | 1 | |
| B43 | HE921C8001 | Hook driving shaft lock stud | 1 | 1 | 1 | 1 | |
| B44 | H4107D0672 | Spring | 1 | 1 | 1 | 1 | |
| B45 | HE922C8001 | Socket | 1 | 1 | 1 | 1 | |
| B46 | H601016100 | Stop | 1 | 1 | 1 | 1 | |
| B47 | HE923C8001 | Hook driving shaft lock ratchet | 1 | 1 | 1 | 1 | |
| B48 | HE035G8001 | Set screw | 1 | 1 | 1 | 1 | |
| B49 | HE034G8001 | Set screw | 1 | 1 | 1 | 1 | |
| B50 | HE924C8001 | Safety clutch pulley | 1 | 1 | 1 | 1 | |
| B51 | H3205C0661 | Spring flange | 1 | 1 | 1 | 1 | |
| B52 | HE021G8001 | Driving shaft position collar | 1 | 1 | 1 | 1 | |
| B53 | HE022G8001 | Set screw | 2 | 2 | 2 | 2 | |
| B54 | HE925C8001 | Safety clutch locking lever spring | 1 | 1 | 1 | 1 | |
| B55 | HE926C8001 | Adjusting screw | 1 | 1 | 1 | 1 | |
| B56 | HE927C8001 | Stud | 1 | 1 | 1 | 1 | |
| B57 | HE028E8001 | Stop screw | 2 | 2 | 2 | 2 | |
| B58 | HE028G8001 | Safety clutch locking lever | 1 | 1 | 1 | 1 | |
| B59 | HE029G8001 | Stud | 1 | 1 | 1 | 1 | |
| B60 | H601012050 | Safety clutch throw-in latch pin | 1 | 1 | 1 | 1 | |
| B61 | HE027G8001 | Connecting link | 1 | 1 | 1 | 1 | |
| B62 | HE026G8001 | Spring | 1 | 1 | 1 | 1 | |
| B63 | HE031G8001 | Safety clutch throw-in latch | 1 | 1 | 1 | 1 | |
| B64 | HE939G8001 | Bobbin winder driving gear | 1 | 1 | 1 | 1 | |
| B65 | H6623C8001 | Screw | 2 | 2 | 2 | 2 | |
| B66 | H3205J0662 | Bearing | 1 | 1 | | | |
| B67 | HF405C8001 | Arm shaft bushing(right) | 1 | 1 | | | |
| B68 | HA100C2020 | Screw | 2 | 2 | | | |
| B69 | HF407C8001 | Machine pulley | 1 | 1 | | | |
| B70 | HE038E8001 | Screw | 2 | 2 | | | |

C. PRESSER FOOT MECHANISM




C. PRESSER FOOT MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|--------------|---------------|--|-----------|-----------|-----------|-----------|---------|
| C01 | HE904D8001 | Needle bar rock frame | | 1 | | 1 | |
| C02 | HE905D8001 | Needle bar rock frame hinge stud | 1 | 1 | 1 | 1 | |
| C03 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| C04 | HE009G8001 | Set screw | 1 | 1 | 1 | 1 | |
| C05 | HE907D8001 | Needle bar connection stud | 1 | 1 | 1 | 1 | |
| C06 | HE041C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| C07 | HE119E8001 | Pinch screw for 70022 | 2 | 2 | 2 | 2 | |
| C08 | HE908D8001 | Needle bar | | 1 | | 1 | |
| C09 | HE909D8001 | Needle | 1 | 2 | 1 | 2 | |
| C10 | HE910D8001 | Needle set screw | | 2 | | 2 | |
| C11 | HE911D8001 | Needle bar rock frame position bracket | 1 | 1 | 1 | 1 | |
| C12 | HE022K8001 | Screw | 1 | 1 | 1 | 1 | |
| C13 | HE912D8001 | Presser bar position guide | 1 | 1 | 1 | 1 | |
| C14 | HE006D8001 | Set screw | 1 | 1 | 1 | 1 | |
| C15 | HE007D8001 | Presser bar bushing (upper) | 1 | 1 | 1 | 1 | |
| C16 | HE006D8001 | Set screw | 2 | 2 | 2 | 2 | |
| C17 | HE913D8001 | Presser bar position guide lever | 1 | 1 | 1 | 1 | |
| C18 | HE009D8001 | Pinch screw | 1 | 1 | 1 | 1 | |
| C19 | HE914D8001 | Presser bar lifting bracket | 1 | 1 | 1 | 1 | |
| C20 | H3107G0661 | Pinch screw | 1 | 1 | 1 | 1 | |
| C21 | HE915D8001 | Presser bar spring bracket | 1 | 1 | 1 | 1 | |
| C22 | HE916D8001 | Pinch screw | 1 | 1 | 1 | 1 | |
| C23 | HE007D8001 | Presser bar bushing (lower) | 1 | 1 | 1 | 1 | |
| C24 | HE918D8001 | Presser bar | 1 | 1 | 1 | 1 | |
| C25 | HE919D8001 | Lifting presser foot | | 1 | | 1 | |
| C26 | HE920D8001 | Pinch screw for lifting presser foot | 1 | 1 | 1 | 1 | |
| C27 | HE921D8001 | Lifting rock shaft | 1 | 1 | 1 | 1 | |
| C28 | HE024D8001 | Lifting rock shaft bushing | 2 | 2 | 2 | 2 | |
| C29 | HE025D8001 | Screw stud | 1 | 1 | 1 | 1 | |
| C30 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| C31 | H3112F0662 | Nut | 1 | 1 | 1 | 1 | |
| C32 | HE922D8001 | Lifting eccentric | 1 | 1 | 1 | 1 | |
| C33 | HE038E8001 | Position screw | 1 | 1 | 1 | 1 | |
| C34 | HE923D8001 | Lifting eccentric connection | 1 | 1 | 1 | 1 | |
| C35 | HE924D8001 | Lifting bell crank | 1 | 1 | 1 | 1 | |
| C36 | H3107G0662 | Set screw | 1 | 1 | 1 | 1 | |
| C37 | HE925D8001 | Lifting bell crank link | 1 | 1 | 1 | 1 | |
| C38 | HE926D8001 | Vibrating presser bar connecting link | 1 | 1 | 1 | 1 | |
| C39 | HE927D8001 | Vibrating presser bar | 1 | 1 | 1 | 1 | |
| C40 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| C41 | HE928D8001 | Vibrating presser foot. | | 1 | | 1 | |

C. PRESSER FOOT MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|--|-----------|-----------|-----------|-----------|---------|
| C42 | HE929D8001 | Set screw for vibrating presser foot | 1 | 1 | 1 | 1 | |
| C43 | HE930D7101 | Needle bar frame rock shaft | | | 1 | 1 | |
| C44 | H3100F2270 | Needle bar rock frame slide block | 1 | 1 | 1 | 1 | |
| C45 | HE027E8001 | Screw stud | 1 | 1 | 1 | 1 | |
| C46 | HE028E8001 | Set screw | 1 | 1 | 1 | 1 | |
| C47 | HE933D8001 | Needle bar rock frame rock shaft crank | 1 | 1 | 1 | 1 | |
| C48 | HE038E8001 | Pinch screw | 1 | 1 | 1 | 1 | |
| C49 | HE934D8001 | Crank connection | 1 | 1 | 1 | 1 | |
| C50 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| C51 | HE935D8001 | Hinge screw | 1 | 1 | 1 | 1 | |
| C52 | HE936D8001 | Nut | 1 | 1 | 1 | 1 | |
| C53 | HE937D8001 | Feed reversing crank screw stud | 1 | 1 | 1 | 1 | |
| C54 | HE938D8001 | Feed reversing crank | 1 | 1 | 1 | 1 | |
| C55 | HE926E8001 | Nut | 1 | 1 | 1 | 1 | |
| C56 | HE038E8001 | Stop screw | 1 | 1 | 1 | 1 | |
| C57 | HF207D8001 | Vibrating presser foot | 1 | | 1 | | |
| C58 | HF304D8001 | Lifting presser foot | 1 | | 1 | | |
| C59 | HE939D8001 | Vinyl tube | 1 | 1 | 1 | 1 | |
| C60 | HF209D8001 | Vibrating presser bar | 1 | 1 | 1 | 1 | |
| C61 | HE044J8001 | Washer | 1 | 1 | 1 | 1 | |
| C62 | HE940D8001 | Nut | 1 | 1 | 1 | 1 | |

D. STITCH REGULATOR MECHANISM




D. STITCH REGULATOR MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|---------------------------------------|-----------|-----------|-----------|-----------|---------|
| D01 | HE946E7101 | Feed driving eccentric | 1 | 1 | 1 | 1 | |
| D02 | HE905E8001 | Flange | 1 | 1 | 1 | 1 | |
| D03 | HE906E8001 | Set screw | 1 | 1 | 1 | 1 | |
| D04 | HE907E8001 | Set screw | 1 | 1 | 1 | 1 | |
| D05 | HE908E8001 | Friction plate | 1 | 1 | 1 | 1 | |
| D06 | HE909E8001 | Stop screw | 2 | 2 | 2 | 2 | |
| D07 | HA100B2110 | Set screw | 2 | 2 | 2 | 2 | |
| D08 | HE910E8001 | Feed driving eccentric.adjusting disc | 1 | 1 | 1 | 1 | |
| D09 | HE911E8001 | Spring | 1 | 1 | 1 | 1 | |
| D10 | HE912E8001 | Collar | 1 | 1 | 1 | 1 | |
| D11 | HE035G8001 | Position screw | 1 | 1 | 1 | 1 | |
| D12 | HE023C8001 | Set screw | 2 | 2 | 2 | 2 | |
| D13 | HE913E8001 | Feed regulating stud | 1 | 1 | 1 | 1 | |
| D14 | HE914E8001 | Spring | 1 | 1 | 1 | 1 | |
| D15 | HE915E8001 | Bushing | 1 | 1 | 1 | 1 | |
| D16 | H601016100 | Retaining spring | 1 | 1 | 1 | 1 | |
| D17 | HE916E8001 | Feed driving connection | 1 | 1 | 1 | 1 | |
| D18 | H4753E8001 | Pinch screw | 1 | 1 | 1 | 1 | |
| D19 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| D20 | HE917E8001 | Feed dog | | 1 | | 1 | |
| D21 | HE918E8001 | Feed dog set screw | | 3 | | 3 | |
| D22 | HE919E8001 | Feed bar | | 1 | | 1 | |
| D23 | HE920E8001 | Feed lifting cam fork | 1 | 1 | 1 | 1 | |
| D24 | H2013J0065 | Washer | 1 | 1 | 1 | 1 | |
| D25 | HE022H8001 | Screw | 1 | 1 | 1 | 1 | |
| D26 | HE020H8001 | Oiling pad | 1 | 1 | 1 | 1 | |
| D27 | HE025B8001 | Screw | 1 | 1 | 1 | 1 | |
| D28 | HE921E8001 | Feed bar crank | 1 | 1 | 1 | 1 | |
| D29 | HE922E8001 | Set screw | 2 | 2 | 2 | 2 | |
| D30 | HE923E8001 | Feed bar hinge screw | 1 | 1 | 1 | 1 | |
| D31 | HE131E8001 | Nut | 1 | 1 | 1 | 1 | |
| D32 | HE925E8001 | Feed driving rock shaft | | | 1 | 1 | |
| D33 | HE033H8001 | Feed driving rock shaft stop collar | 1 | 1 | 1 | 1 | |
| D34 | HE034H8001 | Set screw | 2 | 2 | 2 | 2 | |
| D35 | HE033H8001 | Feed driving rock shaft stop collar | 1 | 1 | 1 | 1 | |
| D36 | HE034H8001 | Set screw | 2 | 2 | 2 | 2 | |
| D37 | HE943E7101 | Feed reversing lever | 1 | 1 | 1 | 1 | |
| D38 | HE928E8001 | Feed reversing lever bushing | 1 | 1 | 1 | 1 | |
| D39 | HE929E8001 | Collar | 1 | 1 | 1 | 1 | |
| D40 | HE012E8001 | Set screw | 1 | 1 | 1 | 1 | |
| D41 | HE930E8001 | Hinge screw | 1 | 1 | 1 | 1 | |

D. STITCH REGULATOR MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|---|-----------|-----------|-----------|-----------|---------|
| D42 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| D43 | HE941E8001 | Nut | 1 | 1 | 1 | 1 | |
| D44 | HE931E8001 | Stop screw | 2 | 2 | 2 | 2 | |
| D45 | HE932E8001 | Feed reversing lever slide block | 1 | 1 | 1 | 1 | |
| D46 | HE933E8001 | Hinge screw | 1 | 1 | 1 | 1 | |
| D47 | HE934E8001 | Feed reversing link | 1 | 1 | 1 | 1 | |
| D48 | HE935E8001 | Spring and treadle connecting link | 1 | 1 | 1 | 1 | |
| D49 | HE936E8001 | Hinge screw nut | 1 | 1 | 1 | 1 | |
| D50 | HE937E8001 | Hinge screw | 1 | 1 | 1 | 1 | |
| D51 | HE035C8001 | Oil wick | 1 | 1 | 1 | 1 | |
| D52 | HE926E8001 | Nut | 1 | 1 | 1 | 1 | |
| D53 | HE938E8001 | Feed reversing crank | 1 | 1 | 1 | 1 | |
| D54 | HE939E8001 | Bracket screw | 2 | 2 | 2 | 2 | |
| D55 | HE945E8001 | Feed reversing lever slide block spring | 1 | 1 | 1 | 1 | |
| D56 | HE940E8001 | Screw | 1 | 1 | 1 | 1 | |
| D57 | HE941E8001 | Nut | 1 | 1 | 1 | 1 | |
| D58 | HE942E8001 | Lining metal | 2 | 2 | 2 | 2 | |
| D59 | H005010080 | Spring washer | 1 | 1 | 1 | 1 | |

E. HOOK SADDLE MECHANISM




E. HOOK SADDLE MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|-------------------------------------|-----------|-----------|-----------|-----------|---------|
| E01 | HE904F8001 | Oil gauge | 1 | 2 | 1 | 2 | |
| E02 | HE039J8001 | Oil gauge guide | 1 | 2 | 1 | 2 | |
| E03 | HE905F8001 | Bobbin case opener lever | 1 | 2 | 1 | 2 | |
| E04 | HE906F8001 | Bobbin case opener lever hinge stud | 1 | 2 | 1 | 2 | |
| E05 | HE018J8001 | Oil wick | 1 | 2 | 1 | 2 | |
| E06 | HE020J8001 | Oil wick vinyl tube | 1 | 2 | 1 | 2 | |
| E07 | HE907F8001 | Bobbin case opener | 1 | 2 | 1 | 2 | |
| E08 | H005004060 | Washer | 1 | 2 | 1 | 2 | |
| E09 | HE909F8001 | Screw | 1 | 2 | 1 | 2 | |
| E10 | HE933F7101 | Bobbin | 1 | 2 | 1 | 2 | |
| E11 | HE911F8001 | Hook | 1 | 2 | 1 | 2 | |
| E12 | HE912F8001 | Bobbin case opener lever link | 1 | 2 | 1 | 2 | |
| E13 | HE017J8001 | Stud | 1 | 2 | 1 | 2 | |
| E14 | HE018J8001 | Oil wick | 1 | 2 | 1 | 2 | |
| E15 | HE019J8001 | Nut | 1 | 2 | 1 | 2 | |
| E16 | HE913F8001 | Hook bushing (upper) | 1 | 2 | 1 | 2 | |
| E17 | HE009J8001 | Set screw | 1 | 2 | 1 | 2 | |
| E18 | HE914F8001 | Hook driving shaft bushing (front) | | 2 | | 2 | |
| E20 | HE020C8001 | Set screw | 2 | 2 | 2 | 2 | |
| E21 | HE915F8001 | Hook saddle (left) | | 1 | | 1 | |
| E22 | HE916F8001 | Hook saddle (right) | 1 | 1 | 1 | 1 | |
| E23 | HE005J8001 | Gasket for hook saddle | | 2 | | 2 | |
| E24 | HE052J8001 | Oil reservoir (left) | | 1 | | 1 | |
| E25 | HE006J8001 | Oil reservoir (right) | 1 | 1 | 1 | 1 | |
| E26 | HE017B8001 | Screw | 7 | 14 | 7 | 14 | |
| E27 | HE046J8001 | Hook saddle screw collar | 1 | 2 | 1 | 2 | |
| E28 | HE046J8001 | Hook saddle screw collar | 1 | 2 | 1 | 2 | |
| E29 | HE048J8001 | Hook saddle screw | 1 | 2 | 1 | 2 | |
| E30 | HE918F8001 | Bed block | 1 | 2 | 1 | 2 | |
| E31 | HE919F8001 | Bed block screw | 2 | 4 | 2 | 4 | |
| E32 | HE055G8001 | Hook driving gear | 1 | 2 | 1 | 2 | |
| E33 | HE920F8001 | Set screw | 1 | 2 | 1 | 2 | |
| E34 | HE921F8001 | Set screw | 1 | 2 | 1 | 2 | |
| E35 | HE010J8001 | Hook driving pinion | 1 | 2 | 1 | 2 | |
| E36 | HE017G8001 | Set screw | 1 | 2 | 1 | 2 | |
| E37 | HE012J8001 | Set screw | 1 | 2 | 1 | 2 | |
| E38 | HE013J8001 | Washer | 1 | 2 | 1 | 2 | |
| E39 | HE014J8001 | Hook bushing (lower) | 1 | 2 | 1 | 2 | |
| E40 | HE009J8001 | Set screw | 1 | 2 | 1 | 2 | |
| E41 | HE040J8001 | Oil adjusting dial | 1 | 2 | 1 | 2 | |
| E42 | HE041J8001 | O-ring | 1 | 2 | 1 | 2 | |

E. HOOK SADDLE MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|--|-----------|-----------|-----------|-----------|----------------|
| E43 | HE045G8001 | Set screw | 1 | 2 | 1 | 2 | |
| E44 | HE049J8001 | Washer | 1 | 2 | 1 | 2 | |
| E45 | HE050J8001 | Hook saddle screw | 1 | 2 | 1 | 2 | |
| E46 | HE058G8001 | Feed lifting cam | 1 | 1 | 1 | 1 | |
| E47 | HE017G8001 | Set screw | 1 | 1 | 1 | 1 | |
| E49 | HE010G8001 | Oil wick | | 2 | | 2 | |
| E50 | HE040D8001 | Set screw | 1 | 1 | 1 | 1 | |
| E51 | HE922F8001 | Hook driving shaft | | | 1 | 1 | |
| E52 | HE923F8001 | Hook driving shaft bushing (center) | 1 | 1 | 1 | 1 | |
| E53 | HE007G8001 | Oil pad | 1 | 1 | 1 | 1 | |
| E54 | HE034G8001 | Set screw | 1 | 1 | 1 | 1 | |
| E55 | HE924F8001 | Hook driving shaft collar | | | 1 | 1 | |
| E56 | HE034H8001 | Position screw | | | 2 | 2 | |
| E57 | HE925F8001 | Hook driving shaft bushing (back) | | | 1 | 1 | |
| E58 | HE926F8001 | Oil pad | | | 2 | 2 | |
| E59 | HE927F8001 | Set screw | | | 1 | 1 | |
| E60 | HE914F8001 | Lower shaft front metal | 1 | | 1 | | |
| E61 | HF405F7101 | Hook driving shaft bushing complete (back) | 1 | 1 | | | |
| E62 | HF406F8001 | Hook driving shaft bushing (back) | 1 | 1 | | | |
| E63 | HA307C0662 | Set screw | 2 | 2 | | | SM1/4 (40) × 6 |
| E64 | H4727H8001 | cover board | 1 | 1 | | | |
| E65 | HA7311C306 | set screw | 3 | 3 | | | |

F. THREAD TENSION REGULATOR MECHANISM




F. THREAD TENSION REGULATOR MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|---|-----------|-----------|-----------|-----------|---------|
| F01 | HE904G8001 | Presser bar spring (flat) | 1 | 1 | 1 | 1 | |
| F02 | HE905G8001 | Presser bar spring (auxiliary) | 1 | 1 | 1 | 1 | |
| F03 | H005006080 | Presser bar spring support screw washer | 1 | 1 | 1 | 1 | |
| F04 | HE907G8001 | Presser bar spring support screw | 1 | 1 | 1 | 1 | |
| F05 | HE908G8001 | Presser bar spring regulating screw | 1 | 1 | 1 | 1 | |
| F06 | HE048D8001 | Presser bar lifting bracket guide screw | 1 | 1 | 1 | 1 | |
| F07 | HE933G7101 | Bobbin complete | 1 | 1 | 1 | 1 | |
| F25 | HE925G8001 | Tension bracket | | 1 | | 1 | |
| F26 | HE910G8001 | Tension release lever | | 1 | | 1 | |
| F27 | HE019K8001 | Screw for tension release lever | 2 | 2 | 2 | 2 | |
| F28 | HE912G8001 | Tension release plunger | 1 | 1 | 1 | 1 | |
| F29 | HE913G8001 | Thread controller covering plate | 1 | 1 | 1 | 1 | |
| F30 | HE046C8001 | Stop screw | 1 | 1 | 1 | 1 | |
| F31 | HE012E8001 | Stop screw | 2 | 2 | 2 | 2 | |
| F32 | HE914G8001 | Thread guide (lower) | 1 | 1 | 1 | 1 | |
| F33 | HE915G8001 | Screw | 2 | 2 | 2 | 2 | |
| F34 | HE916G8001 | Thread controller thread guide (lower) | 1 | 1 | 1 | 1 | |
| F35 | HE018H8001 | Nut | 1 | 1 | 1 | 1 | |
| F36 | HE931G8001 | Thread controller spring stop | | 1 | | 1 | |
| F37 | HE046C8001 | Stop screw | 1 | 1 | 1 | 1 | |
| F38 | HF205G8001 | Thread controller spring | | 1 | | 1 | |
| F39 | HE917G8001 | Thread controller spring stud | 1 | 1 | 1 | 1 | |
| F40 | HE022K8001 | Set screw | 1 | 1 | 1 | 1 | |
| F41 | HE918G8001 | Thread controller disc | 1 | 1 | 1 | 1 | |
| F42 | HE919G8001 | Thread controller stud | | 1 | | 1 | |
| F43 | HE920G8001 | Set screw for thread controller stud | 1 | 1 | 1 | 1 | |
| F44 | HE921G8001 | Thread controller thread guide | | 1 | | 1 | |
| F45 | HE915G8001 | Set screw | 2 | 2 | 2 | 2 | |
| F46 | HE922G8001 | Tension release plunger (short) | 1 | 1 | 1 | 1 | |
| F47 | HE923G8001 | Tension release plunger (long) | | 1 | | 1 | |
| F48 | HA310B0705 | Tension disc | 2 | 4 | 2 | 4 | |
| F49 | HA310B0702 | Tension disc | 1 | 2 | 1 | 2 | |
| F50 | H2206B0671 | Tension spring | 1 | 2 | 1 | 2 | |
| F51 | HA310B0701 | Tension thumb nut | 1 | 2 | 1 | 2 | |
| F54 | HF206G7101 | Tension bracket | 1 | | 1 | | |
| F55 | HF208G8001 | Thread controller thread guide | 1 | | 1 | | |
| F56 | HF209G8001 | Thread controller stud | 1 | | 1 | | |
| F57 | HF210G8001 | Tension release lever | 1 | | 1 | | |
| F58 | HF211G8001 | Thread controller thread guide (lower) | 1 | 1 | 1 | 1 | |
| F59 | HE033B8001 | Thread guide | 1 | 1 | 1 | 1 | |
| F60 | HE032B8001 | Set screw | 1 | 1 | 1 | 1 | |

F. THREAD TENSION REGULATOR MECHANISM

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|-------------------------------|-----------|-----------|-----------|-----------|---------|
| F61 | H3108B0692 | Felt | 1 | 1 | 1 | 1 | |
| F62 | HE929G8001 | Thread controller spring | 1 | | 1 | | |
| F63 | HE930G7101 | Thread controller spring stop | 1 | | 1 | | |




























G. PARTS FOR SINGLE NEEDLE




G. PARTS FOR SINGLE NEEDLE

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|-----------------------------|-----------|-----------|-----------|-----------|---------|
| G01 | HF204D8001 | Needle bar rock frame | 1 | | 1 | | |
| G02 | HF205D8001 | Needle bar | 1 | | 1 | | |
| G03 | H4915J8001 | Set screw | 1 | | 1 | | |
| G04 | HF206D8001 | Thread guide | 1 | | 1 | | |
| G05 | HF210B8001 | Bed plate(left) | 1 | | 1 | | |
| G06 | HF211B8001 | Bed plate(right) | 1 | | 1 | | |
| G07 | HE005H8001 | Throat plate screw | 1 | | 1 | | |
| G08 | HE006H8001 | Throat plate position screw | 1 | | 1 | | |
| G09 | HF209B8001 | Throat plate | 1 | | 1 | | |
| G10 | HF205E8001 | Feed dog | 1 | | 1 | | |
| G11 | HF206E8001 | Feed bar | 1 | | 1 | | |

H. PARTS FOR TWIN NEEDLE

| | | | | | |
|---|---|---|---|---|--------|
|  |  |  |  |  | |
| 1/4" | 3/8" 1/2" | 3/4" 7/8" | 1" 1-1/4" | 1-1/2" 1-3/4" | |
|  |  |  |  |  | |
| 1/4" | 3/8" 1/2" | 3/4" 7/8" | 1" 1-1/4" | 1-1/2" 1-3/4" | |
|  |  |  |  |  | |
| 1/4" | 3/8" 1/2" | 3/4" 7/8" | 1" 1-1/4" | 1-1/2" 1-3/4" | |
|  |  |  |  |  | |
| 1/4" | 3/8" 1/2" | 3/4" 7/8" | 1" 1-1/4" | 1-1/2" 1-3/4" | |
|  |  |  |  |  | |
| 1/4" | 3/8" 1/2" | 3/4" 7/8" | 1" 1-1/4" | 1-1/2" 1-3/4" | |
|  | | |  | | |
| 1/4" | 3/4" | 1-1/2" | 1/2" | 3/4" | 1-1/4" |
| 1/2" | 7/8" | 1-1/4" | 1/4" | 7/8" | 1-1/2" |
| 3/8" | 1" | 1-3/4" | 3/8" | 1" | 1-3/4" |


I. SPECIAL PARTS FOR 20"



I. SPECIAL PARTS FOR 20"

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|-----------------------------|-----------|-----------|-----------|-----------|---------|
| I01 | HF410B8001 | Foot lifting lever | 1 | 1 | | | |
| I02 | HF404C8001 | Arm shaft | 1 | 1 | | | |
| I03 | HF404D7101 | Needle bar frame rock shaft | 1 | 1 | | | |
| I04 | HF404E8001 | Feed driving rock shaft | 1 | 1 | | | |
| I05 | HF404F8001 | Hook driving shaft | 1 | 1 | | | |

J. ACCESSORIES



J. ACCESSORIES

| Fig. Nos. | Parts Nos. | Description | GC20698-5 | GC20698-6 | GC20698-7 | GC20698-8 | Remarks |
|-----------|------------|-----------------------------|-----------|-----------|-----------|-----------|---------|
| J01 | HE933F7101 | Bobbin | 2 | 4 | 2 | 4 | |
| J02 | HA300J2070 | Screw driver (large) | 1 | 1 | 1 | 1 | |
| J03 | HA300J2200 | Screw driver (middle) | 1 | 1 | 1 | 1 | |
| J04 | HA300J2210 | Screw driver (small) | 1 | 1 | 1 | 1 | |
| J05 | HB00001040 | Wrench 4.0 mm | 1 | 1 | 1 | 1 | |
| J06 | HB00001030 | Wrench 3.0 mm | 1 | 1 | 1 | 1 | |
| J07 | HB00001025 | Wrench 2.5 mm | 1 | 1 | 1 | 1 | |
| J08 | HB00001015 | Wrench 1.5 mm | 1 | 1 | 1 | 1 | |
| J09 | HA300J2220 | Double head wrench | 1 | 1 | 1 | 1 | |
| J10 | HE905H8001 | Oil pan | 1 | 1 | 1 | 1 | |
| J11 | 016250 | Nail | 10 | 10 | 10 | 10 | |
| J12 | HE909D8001 | Needle | 3 | 6 | 3 | 6 | |
| J13 | H200400069 | Oiler | 1 | 1 | 1 | 1 | |
| J14 | HA300J2170 | Oil | 1 | 1 | 1 | 1 | |
| J15 | H3200L0120 | Thread stand | 1 | 1 | 1 | 1 | |
| J17 | HA307J0671 | Vibration preventing rubber | 3 | 3 | 3 | 3 | |
| J18 | 016250 | Nail | 6 | 6 | 6 | 6 | |
| J19 | HE010M8001 | Screw | 6 | 6 | 6 | 6 | |
| J20 | HE009M8001 | Bed hinge | 3 | 3 | 3 | 3 | |

SHANGHAI HUIGONG NO.3 SEWING MACHINE FACTORY

ADD: 1418, Yishan Road, Shanghai, China

Zip Code: 201103

Overseas Business: TEL: 86-21-64853303 FAX: 86-21-64854304

E-mail: highlead@online.sh.cn <http://www.highlead.com.cn>

The description covered in this manual is subject to change for improvement of the commodity without notice

2008.10. Printed